


FRENZY 205HB

Assembly instructions.

- (1.) Secure the scooter with both hands, then pull the locking sleeve out of the guide block, holding the locking sleeve in place, lift bars to their upright position.
- (2.) Once handle bars have been lifted to their upright position, release the locking sleeve. Be sure to check that the sleeve has locked into the guide block grooves, securing the scooter bars in the upright position.
- (3.) Unclip the handle bars from the folded position and insert the handle into the T-section of the handle bars. Press the metal button to insert fully and rotate the bar until the button locks into the corresponding hole. There should be no movement once locked.
- (4.) Release the clamp on the upright bar and lift to elevate the handle bars to the desired position. Three different heights can be secured by pressing the metal button and continuing to lift the bars.
- (5.) Once the desired height has been achieved, ensure the metal button has locked into one of the holes on the upright bar before tightening the clamp again.
- (6.) Finally, when you have confirmed the height is correct and noted the ball button has locked into place, pull the clamp lever shut to lock the bars securely. If the clamp is not tight enough turn bolt attached the clamp when the lever is open to tighten.

(!) Always ensure that adjustable parts are locked firmly in place before use!


(!!) To Fold away for carrying, follow the above steps in reverse order; always ensure handle bar grips are clipped into holder when removed from T-section.



(1.)



(2.)



(3.)



(4.)



(5.)



(6.)

FRENZY 205HB

Aufbauanleitung.


- (1.) Halte den Scooter mit beiden Händen fest. Ziehe dann die Verschlussmanschette nach oben aus der Führung und halte sie fest, um den Lenker aufzurichten.
 - (2.) Lasse die Verschlussmanschette zurückfahren, sobald der Lenker aufgerichtet ist. Versichere Dich, dass die Manschette sicher eingerastet ist, damit der Lenker vollständig aufgerichtet ist.
 - (3.) Nimm die Griffe aus den Clips und führe sie seitlich in die Lenkstange ein. Drücke dabei die Metallknöpfe herunter und lasse sie durch Drücken und Drehen der Griffe vollständig in die korrespondierenden Löcher einrasten. Danach sollte man die Griffe nicht mehr bewegen können.
 - (4.) Löse die Klemme an der Lenkstange unterhalb des Lenkers, um die Höhe des Lenkers einzustellen. Es gibt 3 Positionen, welche durch die Löcher in der Lenkstange bestimmt werden.
 - (5.) Wenn die richtige Höhe erreicht ist, muss der Metallknopf in das entsprechende Loch einrasten, bevor die Klemme wieder festgestellt wird.
 - (6.) Zum Schluss, wenn die richtige Höhe eingestellt ist und der Metallknopf eingerastet ist, muss der Hebel an der Klemme festgezogen werden. Sollte die Klemme sich nicht fest genug anziehen lassen, muss die daran befindliche Schraube bei geöffneter Klemme leicht angezogen werden.
- (!) Versichere Dich immer, dass verstellbare Teile fest angezogen bzw. eingerastet sind!
- (!!) Um den Scooter einzuklappen, folge den o.g. Schritten einfach in umgekehrter Reihenfolge. Die Griffe müssen wieder in die Clips gesteckt werden, nachdem sie aus dem Lenker gezogen wurden.



(1.)



(2.)



(3.)



(4.)



(5.)



(6.)