


# INFLATING THE TYRES

The Tyres Of This Scooter Are Inflated To 50% Due To Transport Conditions.

The Tyres Should Be Inflated Using The Following Instructions Before Use.



1. Remove valve cap
2. Using a schrader valve type pump inflate the tyre to the required pressure. We recommend a pressure of 2-2.5 bar/29-36 psi.  
**DO NOT EXCEED 2.5BAR AS THIS MAY DAMAGE THE TYRE AND WHEEL**
3. Close the valve cap ensuring that valve cap is tightly closed.
4. Please check the tyre pressures before each use and if required inflate with air. Ride comfort and speed are strongly dependant on the tyre pressures.